

BS12K SERIES

12kW Auto Focus Smart Laser Cutting Head - User Manual





Document History

Edit date	Version	Topic, revision, action taken
2023/4/20	V1.0	First edition
2023/11/28	V2.0	 Alarm info modification Add requirements of antifreeze and water Add common consumables.

Thank you for choosing our product!

This manual describes the installation and commissioning of laser cutting head in details so that you can use this product quickly. You can consult us directly for more details.

Due to the continuous updating of product functions, the product you receive may differ from the introduction in this manual in some aspects.

We reserve all rights in this document including the issued patents and other registered commercial ownership related to this document. It is strictly prohibited to use this document in an improper way especially to copy and disseminate it to third parties.

If you find any errors in this document, please inform us as soon as possible. The data contained in this manual is only used to describe the product and shall not be regarded as a statement of security interest.

For the benefit of our customers, we will constantly try to ensure that the products we develop comply with the latest technology.

Raytools AG

Email: sales@raytools.com Website: www.raytools.ch



Disclaimer

- We reserve the right to change the design in order to improve the quality or expand the application or comply to manufacturing workmanship.
- We will not bear any responsibility for losses and accidents caused by wrong operation or improper handling of our products.
- Dismantling of product will lose all warranty claims excluding the normal replacement of worn parts and components required for maintenance or commissioning operations.
- Unauthorized modification of products or use of non-original spare parts will directly lead to the invalidation of warranty and liability exemption.
- It is recommended to only use the spare parts provided by us or submit them to us or the designated professional team for installation.

Use Regulations

- Ensure that the product is used in a dry environment.
- Ensure that the product is used in the environment required by EMC standards.
- The product is only allowed to run within the parameters specified in the technical data.

Personnel Responsibilities

- Be familiar with the basic provisions of work safety & accident prevention and have received equipment operation guidance.
- Read and understand basic safety instructions and operations.
- You must have studied the relevant regulations and safety instructions and understand the possible hazards.
- Comply with relevant regulations and implement corresponding protective measures.



Safety Instructions

Prevent Electric Shock

Parts of the laser head such as nozzle, sensor, sensor interface and attached fasteners may not be fully protected by the ground wire due to function fault. These parts may have low voltage. When installing electrical equipment, please pay attention to taking anti electric shock measures for relevant personnel.



Note that the equipment shall be grounded as specified.

Guard against Danger

- Never put your hands or other body under the laser head.
- Repair and maintenance work can only be carried out after the power is turned off.
- Do not exceed the specified maximum pressure.
- It must be ensured that the laser head is in normal condition at all times.
- All fasteners such as bolts and nuts must be tightened.



Laser Caution

- Avoid direct laser radiation or scattering to the skin.
- Do not stare at the laser beam even when wearing optical equipment.
- Use special laser protective eyeglasses that meet the requirements of safety standards IEC 60825-1.

Prevent Waterway Corrosion

 In order to avoid corrosion, use the specified coolant and comply with relevant requirements and specified maintenance intervals.

Noise Prevention

 The corresponding measures shall be specified or explained and observed in order to prevent personnel from being harmed by noise when the cutting air pressure is high.

Storage and Transportation

- Observe the storage temperature range allowed by the technical data.
- Take reasonable measures to prevent fire, vibration or impact.
- Do not store in or near the magnetic field.



Contents

1	Product Summary1
1.1	Structure (with QBH Interface)1
1.2	Function
1.3	Technical Datasheet
1.4	Mechanical Size5
1.5	Physical Interface
2	Mechanical Installation7
2.1	Fiber Insertion7
2.2	Mounting of Laser Cutting Head9
2.3	Earthing of Laser Cutting Head10
2.4	Inspection of Top Cover Glass (1 st Installation/Replacement of Fiber)11
2.5	Connection of Cooling Water and Assist Gas12
3	System Installation and Commissioning14
3.1	Auto Focus by 0-10V Analog14
3.2	Auto Focus by EtherCAT
3.3	Mobile APP19
4	Beam Alignment and Zero Focus Correction
4.1	Beam Alignment
4.2	Focus Position Setting
5	Maintenance
5.1	Cleaning Lens
5.2	Removal and Installation of Lenses25
5.3	Replace Ceramic Body and Nozzle
Con	sumables

1 Product Summary

RAYTOOLS

1.1 Structure (with QBH Interface)





- 1 Water Cooling Interface (□8)
- 2 Dual Top Cover Glass
- 3 Cutting Gas Interface (□12)
- 4 Water Cooling Interface (□8)
- **5** Retaining Ring
- 6 Water Cooling Module
- 7 Water Cooling Interface (□8)

- 9 Water Cooling Interface (□8)
- 10 Nozzle
- 11 Preamplifier Interface (SMA)
- 12 Fiber Interface
- 13 Control Interface
- 14 Focus Module/XY Alignment
- 15 Middle Cover Glass Assy
- 16 Bottom Cover Glass Assy
- 17 LED

1.2 Function

1.2.1 Protection and Monitoring

- Cutting gas pressure detection
- Bottom cover glass ready detection
- Temperature detection of bottom cover glass
- Temperature detection of top cover glass
- Cavity gas pressure detection
- Cavity temperature detection
- Dual top cover glass

1.2.2 Smart Monitoring

- Compatible with PC
- Compatible with Android

1.2.3 LED

LED Status Definition (from left to right):





LED No.	LED Status	Status Definition	
LED 1	Light off	Focus not homed or homing failed	
	Green on	Running normally	
	Green blinks	Focus motor homing	
	Red on	Cavity fault	
	Light off	Dew point alarm (closable)	
	Green on	Running normally	
	• Padan	Abnormal temperature of top cover	
LED 2	- Red on	glass / temperature rise alarm	
	• • Dad bliste	Abnormal temperature of top cover	
		glass / temperature rise precaution	
	Light off	Cavity pressure alarm	
	Green on	Running normally	
	• Dad an	Abnormal temperature of focus lens/	
LED 3	- Red on	temperature rise alarm	
		Abnormal temperature of focus lens/	
	Red blinks	temperature rise precaution	
	Light off	Bottom cover glass not ready for operation	
	Green on	Running normally	
LED 4	•	Abnormal temperature of bottom cover	
	- Red on	glass/ temperature rise alarm	
		Abnormal temperature of bottom cover	
	Red blinks	glass/ temperature rise precaution	
Remark: 4-green LED and 4-red LED will blink alternately while online upgrading.			

1.3 Technical Datasheet

Model	BS12K
Wavelength	1080nm
Fiber Interface	QBH/LOE/QD/Q+
Power Rating	12kW
Collimation Length (fC)	100mm
Focusing Length (fF)	200mm
NA max	0.14
Auto Focus Range	-40mm+40mm
Beam Alignment Range	-1.5mm+1.5mm
Mounting Size of Cutting Head	4xM6
Mounting Size of Preamplifier	4xM3
Cutting Gas	ø12, max. 25bar
Water Cooling	Ø8, max. 5bar, min. 1.5L/min
Operating Voltage	24V±10%, max. 4A
I/O Interface (19-Pin)	Output current must be less than 30mA
Operating Temperature	5℃~55℃
Humidity	$30\%{\sim}95\%$, without condensing
Weight	8.3kg \sim 8.7kg

1.4 Mechanical Size

RAYTOOLS

Optical Configuration 100:200



5

൭

0 0 0 0

7

1.5 Physical Interface



No. 1	Cooling water (Ø8)	No. 5	Cooling water (Ø8)
No. 2	Cooling water (Ø8)	No. 6	Preamplifier (SMA)
No. 3	Cutting gas (Ø12)	No. 7	Control interface
No. 4	Cooling water (Ø8)		



Please note connection size and max. capacity of interface.

2 Mechanical Installation

RAYTOOLS

2.1 Fiber Insertion



WARNING: The optical components must be dust free and all dusts must be cleaned before use. The fiber shall be horizontally inserted into fiber interface to prevent dust from entering the interface and falling on the lens. Clean the upside of the fiber before inserting into the laser head.

2.1.1 QBH Fiber Insertion



- Align the red point at the end of the QBH interface to the red point of the handwheel.
- Remove QBH dustproof cover.
- Align the red mark of fiber end to red mark on QBH of cutting head. Then insert the fiber straightly to the bottom of the QBH interface.
- Turn the QBH handwheel clockwise. It is in place when you hear the "Da" voice, then pull the handwheel up and turn clockwise to end.



2.1.2 LOE Fiber Insertion



- Remove the dust cover of LOE adaptor.
- Align the locating pin holes of the fiber end and the laser head.
- Lock the fiber end and the laser head with locking screws tightened to the corresponding screw holes.
- Shake the fiber gently after locked, to confirm it is tightened prior to use.



It is recommended to use textured tape to seal the connection of female and male fiber interface after the installation is finished in order to prevent from dust as much as possible in critical dusty environment.

2.2 Mounting of Laser Cutting Head

RAYTOOLS

The mounting of laser cutting head to machine tool is shown as below. Customers are advised to Install the laser head perpendicular to the bed surface as requested and make sure the laser head is locked, which is one of the premises to ensure the stable cutting.



2.3 Earthing of Laser Cutting Head





The shaking or vibration of cutting head due to incorrect earthing could cause damage to sensor mechanism and machine.

2.4 Inspection of Top Cover Glass (1st Installation/Replacement of Fiber)

Maintenance or repair shall be implemented at dust free workstation.



- Loose bolts (item 1) and pull out the glass holder until you see the complete cover glass.
- Seal the openings of cutting head by textured tape immediately.
- Check if the top cover glass is clean. If not, blow the cover glass by clean compressed air until it is clean.

The cover glass shall be replaced if it cannot be cleaned or a damage happens.

2.5 Connection of Cooling Water and Assist Gas

2.5.1 Connection of Cutting Gas

RAYTOOLS



The impurity in cutting gas such as hydrocarbon and steam will damage the lens and cause cutting power fluctuation as well as inconsistencies between the sections of the work piece. The table below is the recommended cutting gas specification.

Gas	Purity	Maximum content of water vapor		Maximum content of hydrocarbon
Oxygen	>99.5%		<5 ppm	<1 ppm
Nitrogen	>99.95%		<5 ppm	<1 ppm
Diameter of cutting gas pipe (Outer diameter)		ø12mm (G)		
Gas Pressure		Max. 25bar (2.5MPa)		

CAUTION: Gas interface cannot be replaced arbitrarily especially do not use PTFE TAPE. Otherwise the gas path will be blocked and cannot do normal cutting which will damage cutting head at the same time.



2.5.2 Connection of Cooling Water



To avoid affecting follow capacitance, it's recommended to select blade battery antifreeze with conductivity less than 3us/cm. The recommended water flow is suggested below.

- Cooling pipeline of fiber interface: W1, W2
- Cooling pipeline of collimation module: W3, W4
- Cooling pipeline of the machine: W5, W6.

The cooling water must comply with the technical standards in the table below.

Outer diameter of water hose	ø8mm
Minimum flow speed	1.5 l/min
Entry pressure	170-520kPa
Entry temperature	≥room temperature />dew point
Hardness (relative to CaCO ₃)	<250mg/liter
PH range	6 to 8
Particle size allowed	Diameter less than 200 microns

3 System Installation and Commissioning

3.1 Auto Focus by 0-10V Analog

RAYTOOLS



- Connect ① the 19-pin interface of laser head with ③ I/O-CAN board by ② the control cable
- Connect all necessary I/O interfaces with CNC
- Connect 24V power supply to the I/O-CAN board
- With *Raytools* motion control system, user can check the default parameter.
- For other system of *WEIHONG* or *FSCUT*, complete configuration and commissioning according to the system instruction.

I/O-CAN Board



I/O-CAN Definition

Pin No.	Item	Definition
1	Power supply 24V	24V to power supply
2	Power supply 0V	OV to power supply
3	I/O 24V	24V to I/O
4	I/O 0V	0V to I/O
5	RS485+	485 communication
6	RS485-	485 communication
		24V (Uperedge): Manually homing enable (Keep
7	Input-Home	PNP while homing)
		Else: Home disable
o	Input Focus	24V (Uperedge): Focus enable
0	input-rocus	Else: Focus disable
0	Output Alarm	Floating: Alarm
9	Output-Alarm	0V: no alarm
10	Output Fague reached	0V: Focus reached
10	Output-Focus reached	Floating: Focus unreached
11	Input-Analog +	
12	Input-Analog -	0.5V-3.7V AULO IOCUS

Remark: connect Pin 11, Pin 12 by the complimentary shielded twisted pair.



Take the connection to FSCUT system as an example:



Wiring diagram

After the wiring is completed, enter the system setting. The following parameters are only for reference.

Raytools system setting:

rand	Focus adjmt	
Raytools 👻	Laser Head Parameter	Curve of voltage focus point
lodel	Voltage range (V) 0.3 • ~ 9.7 •	10 to 1
3512K 👻	Focal range (mm) 40 - ~ -40 -	
ocus control mode	Voltage of zero focus 5 - v	24
-10V Analog output 👻	Forming anable delay 300 x ms	
eight sensor type		8
DS On Board 👻	Keturn to origin delay 10000 * MS	
eight sensor signal port	Focus analog output Slave ID4: AO_1	
lave ID4:Height Sensor Capaci 🔻	Focus enable Slave ID4: DO_3	
	Return to origin Slave ID4: DO_5	-24
	Cutting head alarm Slave ID4: DI_16	
	Shield cutting head alarm	-40
		1 2 3 4 5 6 7 8 9
		voitage v

FSCUT system setting:



The connections and settings may differ from one CNC control system to another. Once the setting is modified, the corresponding wiring method may need to be changed.

i



3.2 Auto Focus by EtherCAT





EPOE24

- Connect 24V power supply to the I/O board (EPOE24)
- Connect by network cable as shown above
- Complete configuration and commissioning according to the system instruction (including Raytools or Beckhoff)

EPOE24 Definition

No.	Definition	Remark
IN	Input-Interface	Signal input
OUT	Output-Interface	Signal output
24V	Power supply 24V	24V to power supply
GND	Power supply OV	0V to power supply
PE	Earthing	For earthing

3.3 Mobile APP

- Start the app and operate connection according to the instruction.
- Set by manual input based on actual needs.

Examples as below:

Item	Remark	Set Value
Zero Focus Offset	To correct according to actual zero focus position	
Alarm Temp-Top Cover Glass	Alarm threshold 45 $^\circ \! \mathbb{C}$	45 ℃
Alarm Temp-Bottom Cover Glass	Alarm threshold 45 $^\circ \! \mathbb{C}$	45 ℃
Alarm Temp- Focus Lens	Alarm threshold 45 $^\circ \! \mathbb{C}$	45 ℃
Alarm Temp- Cavity	Alarm threshold 45 $^\circ \! \mathbb{C}$	45 ℃
Alarm Pressure-Cavity	Alarm threshold 1.5 bar	1.5 bar

PC monitoring can display the data after connecting its USB or wifi to the hotspot of the cutting head.





BS12K SERIES 12kW Auto Focus Smart Laser Cutting Head-User Manual



Open the monitoring software and there will be a hover ball on top of the display, double click the hover ball to display detailed information.



Real-time sensor data can be monitored manually. If an alarm occurs in the cutting head, history data for 1 minute prior to the alarm is auto-recorded.





Note: The RS-485 to USB cable will be attached with the head to connect with HMI PC.

4 Beam Alignment and Zero Focus Correction

4.1 Beam Alignment

Lens alignment of laser cutting head can be finished by adjusting focus lens, X-Y direction. The X/Y adjusting knob is located above bottom cover glass as shown below. Adjusting the 2 knobs until the beam is located in the middle of nozzle. Make sure the laser beam output from the center of nozzle. A method commonly used is tape dotting method as below:

- Fix the cutting head with a big size nozzle (tip size shall be larger than beam size) or adjust to nearly zero focus.
- Pick a scotch tape, flatten it and stick it to the nozzle tip.
- Open the red light of the laser. Find and observe the position of red light in the scotch tape.
- Shoot laser at low power to check beam penetration size. Beam penetration shall be circle and located in the nozzle tip center.
- Adjust the 2 X/Y adjusting knobs to get beam aligned. The max X/Y adjusting range is roughly from -1.5mm to +1.5mm.
- Tear off the tape and check the shooting hole position in tape.
- Repeat the above steps to find out relatively centered position.



4.2 Focus Position Setting

Focus & Voltage Curve



Note:

- 1. CL100mm/FL200mm: 0.3V corresponds to +40mm. 9.7V corresponds to -40mm.
- 2. Mechanical and optical manufacturing tolerance, matching tolerance between imaging proportion of optical component and optical fiber will have other effects on the actual focus position.
- 3. Adjust the focus offset according to the actual situation.

5 Maintenance

5.1 Cleaning Lens

It's necessary to maintain lenses regularly because of the characteristic of laser cutting process. Cleaning to the cover glass once a week is recommended. The collimating lenses and focusing lenses are recommended to be cleaned once every 2~3 months. In order to facilitate the maintenance of the cover glass, the cover glass holder adopts a drawer type structure.

Tools: Dust-proof gloves or fingertip, polyester swab, absolute ethanol, rubber gas blow (purely compressed air).

Cleaning instruction:

- To put fingertip onto left thumb and index finger.
- Spray absolute ethanol onto the polyester swab.
- Hold the edge of the lens with left thumb and index finger gently. (note: avoid touching the surface of the lens by fingertip in case of trace)
- Hold the lens to face eyes by left hand and hold the polyester swab by right hand. Wipe the lens gently
 in single direction, from bottom to top or from left to right (Should not wipe back and forth in case of
 secondary pollution to lens) and use rubber blow (purely compressed air) to blow the surface of the
 lens. Both surfaces should be cleaned. After cleaning, make sure that there is no residual like detergent,
 floating ash, foreign matters and impurities.

5.2 Removal and Installation of Lenses

RAYTOOLS

The whole process needs to be completed in a dust free room. Wear dust-proof gloves or fingertips when removing or installing the lenses.

5.2.1 Removal and Installation of Bottom Cover Glass/Protection Glass

The cover glass is wearing part which needs to be replaced once it is damaged.



- As shown above, loose the 2 bolts to pull out cover glass holder by pinching 2 edges of drawer type holder.
- Seal the mounting openings by textured tape immediately.
- Remove the pressing ring (1) and cover glass (2) after wearing fingertips
- Clean the cover glass holder and seal ring (3). The elastic seal ring (3) should be replaced if it is damaged.
- Install the cleaned or new cover glass (regardless of the front or back surface) into the holder of cover glass.
- Install the pressing ring.
- Insert the cover glass holder back to the laser head and tighten the bolts.



It is not allowed to pull out the edge of seal ring directly as it is very easy to damage the seal ring.

Please wear the clean gloves or fingertips.

5.2.2 Removal and Installation of Middle Cover Glass/Protection Glass

The cover glass is wearing part which needs to be replaced once it is damaged.



- As shown above, loose the 2 bolts to pull out cover glass holder by pinching 2 edges of drawer type holder.
- Seal the mounting openings by textured tape immediately.
- Remove the pressing ring (1) and cover glass (2) after wearing fingertips
- Clean the cover glass holder and seal ring (3). The elastic seal ring (3) should be replaced if it is damaged.
- Install the cleaned or new cover glass (regardless of the front or back surface) into the holder of cover glass.
- Install the pressing ring.
- Insert the cover glass holder back to the laser head and tighten the bolts.



It is not allowed to pull out the edge of seal ring directly as it is very easy to damage the seal ring. Please wear the clean gloves or fingertips.

5.3 Replace Ceramic Body and Nozzle

RAYTOOLS



The nozzle is required to be replaced if it gets crash or damaged by laser beam. The dirt on ceramic body is required to be cleaned or to replace the ceramic body if it gets crash.

- Unscrew the nozzle (1) and remove washer (2) and cooling module (3).
- Press the ceramic body (5) upward by hand to make it fixed without deflection and then unscrew the retaining ring (4).
- Align the pin hole of the new ceramic body with the locating pin. Press the ceramic body (5) upward by hand and tighten the retaining ring (4).
- Install the cooling module (3) and washer (2). Screw the nozzle (1) and get it properly tightened.
- Do the capacitance calibration once again after replacing the nozzle or ceramic body.



Only tighten the nozzle and ceramic ring by hand (without tools) otherwise it could damage the ceramic body.

Keep the contact surface of all parts clean.



Consumables

Name	Technical Data	Material Code
Fiber Interface	QBH	211FIA3003
	Q+	211FIA4003
	QD	211FIA3007
	LOE3.2	120BS5002A
Collimation Lens	Biconvex spherical lens	3250010280
	Meniscus spherical lens	3250010281
Focus Lens	Biconvex spherical lens	3250010433
	Meniscus spherical lens	3250010420
Cover Glass	D24.9 x 1.5	211LCG0086
	D37 x 7	211LCG0078
Nozzle	2D Single layer M11 - Ø1.2	120GJT5112
	2D Single layer M11 - Ø1.3	120GJT5113
	2D Single layer M11 - Ø1.5	120GJT5115
	2D Single layer M11 - Ø1.7	120GJT5117
	2D Single layer M11 - Ø1.9	120GJT5119
	2D Single layer M11 - Ø2.1	120GJT5121
	2D Single layer M11 - Ø2.3	120GJT5123
	2D Single layer M11 - Ø2.5	120GJT5125
	2D Double layer M11 - Ø1.2	120GJT7212
	2D Double layer M11 - Ø1.3	120GJT7213
	2D Double layer M11 - Ø1.4	120GJT7214
	2D Double layer M11 - Ø1.6	120GJT7216
	2D Double layer M11 - Ø1.8	120GJT7218
	2D Single layer M11 - Ø1.5	120GJT9115
	2D Single layer M11 - Ø2.0	120GJT9120
	2D Single layer M11 - Ø3.0	120GJT9130
	2D Single layer M11 - Ø4.0	120GJT9140
	2D Single layer M11 - Ø5.0	120GJT9150
	2D Single layer M11 - Ø6.0	120GJT9160
	2D Single layer M11 - Ø7.0	120GJT9170
Ceramic Body	D41- M11	120515089A